

Mounting description for Recline release handle Netti Svipp for armrest.

To fix the release handle, you must unfix the foremost screw under the armrest pads.
Put a M5x35 screw through the fixing hole on the release handle, and mount it under the armrest pad with the existing screw.

